



DEPARTURE ROUTE DESCRIPTION

LOSS OF COMMUNICATIONS: In the event of a loss of communication, aircraft shall comply with the last acknowledged clearance up to the next reporting point in the departure procedure, then climb to the flight planned cruising level and follow the departure procedure.

TAKE-OFF RWY 07L: Climb to 5000. Track 073° direct to SMT VOR/DME. At SMT VOR/DME intcp R-087 to ROACH. At ROACH turn right track direct BREAM. Thence.....

TAKE-OFF RWY 07R: Climb to 5000. Track 073° to PORPA. At PORPA turn right track direct to BREAM. Thence.....

ATTOL 1A, 1C DEPARTURE: At BREAM turn right direct ATTOL. Continue via V9 transition. Expect further climb when instructed by ATC to cross BREAM at FL130.

BEKOL 1E, 1F DEPARTURE: At BREAM turn left direct TD VOR/DME turn left direct BEKOL. Further climb when instructed by ATC. If TD VOR/DME is not available, expect radar vectors from BREAM to BEKOL.

LAKES 1E, 1F DEPARTURE: At BREAM turn left direct LAKES. Continue via V1 transition. Further climb when instructed by ATC.

OCEAN 1E, 1F DEPARTURE: At BREAM turn left direct OCEAN. Continue via V2, V3, V4 or V5 transition. Further climb when instructed by ATC.

SANDI 1A, 1C DEPARTURE: At BREAM turn right direct PERCH direct SANDI. Continue via V6, V7 or V8 transition. Expect further climb when instructed by ATC to cross BREAM at FL130.

V1 TRANSITION: At LAKES proceed direct SOUSA direct DOTMI.

V2 TRANSITION: At OCEAN proceed direct CONGA direct ELATO.

V3 TRANSITION: At OCEAN proceed direct CONGA direct ENVAR.

V4 TRANSITION: At OCEAN proceed direct GRUPA direct NOMAN.

V5 TRANSITION: At OCEAN proceed direct GRUPA direct SABNO.

V6 TRANSITION: At SANDI proceed direct EPDOS.

V7 TRANSITION: At SANDI proceed direct WAYEL direct IDOSI.

V8 TRANSITION: At SANDI proceed direct WAYEL direct DAGON.

V9 TRANSITION: At ATTOL proceed direct DOFIN direct SIKOU.